

ATTACHMENT 3
PREVENTIVE MAINTENANCE REPAIR COMPONENTS INCLUDED

Elevators

Repairs to, or replacement of, covered unit components must include, but not necessarily be limited to the following:

- 1) Brake magnet coils and stators, brake shoes and linings.
- 2) Controller, selector, and dispatching equipment.
- 3) Relays, resistors, condensers, and transformers.
- 4) Contacts, leads, dashpots, and timing devices.
- 5) Steel selector tapes, and mechanical and electrical driving equipment.
- 6) Governor, governor sheave, and shaft assembly.
- 7) Governor bearing, contacts, and governor jaws.
- 8) Governor tension and sheave assembly.
- 9) Counterweight and counter weight guide shoes, including rollers or gibs.
- 10) Hoistway door interlocks and hangers.
- 11) Car door guides, sill guide tracks, and auxiliary door closing devices.
- 12) Car door hanger, contact, and power operator.
- 13) Car guide shoes, gibs, or rollers.
- 14) Hydraulic pumps and valves.
- 15) Packing for hydraulic jacks.
- 16) Drive belts and sheaves.
- 17) Leveling devices.
- 18) Push buttons and indicator lamps.
- 19) Car lamps, light fixtures, and ventilating fans.
- 20) Repair and adjustment of motor and gearing assemblies.
- 21) Emergency light system and batteries.
- 22) Replacing Ropes